

	Medstead				
A1	NTU - X and R 01-05	B1	NTU - X and R 01-05	C1	NTU - line
A2	NTU - X and R 06-10	B2	NTU - X and R 06-10	C2	ties to MDF prs 01-10
A3		B3	station alarm panel - incoming alarms from MDF	C3	ties to MDF prs 11-20
A4		B4		C4	ties to MDF prs 21-30
A5		B5		C5	ties to MDF prs 31-40