







- Sig Box Fuses
- 1 CODE PHONE
 - 2 MISC R/SET
 - 3 SPT CONC
 - 4 BJ 1st Floor
 - 5 BJ 2nd Floor



- EXCHANGE - SIGNAL BOX
- 1 431
 - 2 CODE
 - 3 430
 - 4 PF TELE
 - 5
 - 6 SPT TEST
 - 10 690
 - 11 BELL TO STATION
 - 12 BZ TO STATION
 - 17 BZ FROM SIGNAL
 - 20 LEFH

ANUB