

U pt		LEAD	KRONE	U pt		LEAD
1	WH	1AL	1/01L	2	RD	REC ATTN 1
3	BL	2AL	1/01R	4	GR	REC ATTN 2
5	WH	3AL	1/02L	6	RD	
7	OR	4AL	1/02R	8	BR	remote alarm panel
9	or(wh)	unit out teed to part2 u29	5/07R	10	wh(bl)	BATT 1
11	gr(wh)	ETH	5/08R	12	wh(or)	BATT 2
13	WH	5AL	1/03L	14	RD	SIGNAL BOX ALARM
15	GR	6AL	1/03R	16	SL	SIGNAL BOX ALARM
17	WH		1/04L	18	BK	LED 01 panel 1
19	BR		1/04R	20	BL	LED 02 panel 1
21	WH	SU 101	1/05L	22	BK	LED 03 panel 1
23	SL	SU 101	1/05R	24	OR	LED 04 panel 1
25	RD	SU 101	1/06L	26	BK	LED 05 panel 1
27	BL	SU 101	1/06R	28	GR	LED 06 panel 1
29	RD	SU 101	1/07L	30	BK	LED 07 panel 1
31	OR	SU 101	1/07R	32	BR	LED 08 panel 1
51	BK	LED 09 panel 1	2/05L	52	BL/WH	MF relay
53	SL	LED 10 panel 1	2/05R	54	GR	MF relay
55	YL	LED 01 panel 2	2/06L	56	BL/RD	
57	BL	LED 02 panel 2	2/06R	58	BR	
59	YL	LED 03 panel 2	2/07L	60	BL/RD	
61	OR	LED 04 panel 2	2/07R	62	SL	
63	YL	LED 05 panel 2	2/08L	64	BL/RD	LED 01 panel 3
65	GR	LED 06 panel 2	2/08R	66	BL	LED 02 panel 3
67	YL	LED 07 panel 2	2/09L	68	BL/RD	LED 03 panel 3
69	BR	LED 08 panel 2	2/09R	70	OR	LED 04 panel 3
71	YL	LED 09 panel 2	2/10L	72	BL/RD	LED 05 panel 3
73	SL	LED 10 panel 2	2/10R	74	GR	LED 06 panel 3
75	BL/WH	FA alarm	3/01L	76	BL/RD	LED 07 panel 3
77	BL	MF alarm	3/01R	78	BR	LED 08 panel 3
79	BL/WH	FA relay coil tag b	3/02L	80	BL/RD	LED 09 panel 3
81	OR	FA relay coil tag d	3/02R	82	SL	LED 10 panel 3
101	BL/BK	ALM 0 - Netiom	4/01L	102	BL/YL	5v from Netiom
103	BL	ALM 1	4/01R	104	BR	
105	BL/BK	ALM 2	4/02L	106	BL/YL	BUZZER 1
107	OR	ALM 3	4/02R	108	SL	BUZZER 2
109	BL/BK	ALM 4	4/03L	110	wh/bl	
111	GR	ALM 5	4/03R	112	bl/wh	Z pulse
113	BL/BK	ALM 6	4/04L	114	wh/or	
115	BR	Rec attn - local	4/04R	116	or/wh	
117	BL/BK	Rec attn - remote	4/05L	118	wh/gr	S pulse
119	SL		4/05R	120	gr/wh	
121	BL/YL		4/06L	122		
123	BL		4/06R	124		
125	BL/YL		4/07L	126		
127	OR		4/07R	128	bl(wh)	5v from DC/DC converter
129	BL/YL		4/08L	130		
131	GR		4/08R	132	wh(gr)	50v to DC/DC converter

RP05
KRONE
1/08L
1/08R
1/09L
1/09R
5/06L
5/07R
1/10L
1/10R
2/01L
2/01R
2/02L
2/02R
2/03L
2/03R
2/04L
2/04R
3/03L
3/03R
3/04L
3/04R
3/05L
3/05R
3/06L
3/06R
3/07L
3/07R
3/08L
3/08R
3/09L
3/09R
3/10L
3/10R
4/09L
4/09R
4/10L
4/10R
part 2 u2
u4
u6
u8
u1
u3
5/06R
5/08L