

Alton alarm relay set						Dec-07
EQUIP		LEAD	KRONE		LEAD	KRONE
1ALe	WH	1AL	1/01L		ETH COMMON	4/01L
2ALe	BL	2AL	1/01R		ETH COMMON	4/01R
3ALe	WH	3AL	1/02L		ETH COMMON	4/02L
4ALe	OR	4AL	1/02R		ETH COMMON	4/02R
5ALe	WH	5AL	1/03L		ETH COMMON	4/03L
6ALe	GR	6AL	1/03R		ETH COMMON	4/03R
AZ2	WH	BUZZER 1	1/04L		ETH COMMON	4/04L
AZ22	BR	BUZZER 2	1/04R		ETH COMMON	4/04R
RA tag a	WH	REC ATTN 1	1/05L	WH	MDF tie 1a - faulty pair?	4/05L
	SL	REC ATTN 2	1/05R	BL	MDF tie 1b - faulty pair?	4/05R
AX1	RD	Signal box - alm/no alm	1/06L	WH	MDF tie 2a	4/06L
AX3	BL	Signal box - alm/no alm	1/06R	OR	MDF tie 2b	4/06R
AX21	RD	SU 101	1/07L	WH	MDF tie 3a	4/07L
RX tag A	OR	SU 101	1/07R	GR	MDF tie 3b	4/07R
FA1	RD	FA alarm	1/08L	WH	MDF tie 4a	4/08L
MF1	GR	MF alarm	1/08R	BR	MDF tie 4b	4/08R
MF tag a	RD	MF relay coil	1/09L	WH	MDF tie 5a - not term MDF	4/09L
MF tag e	BR	MF relay coil	1/09R	SL	MDF tie 5b - not term MDF	4/09R
FA tag a	RD	FA relay coil	1/10L	RD	MDF tie 6a - not term MDF	4/10L
FA tag e	SL	FA relay coil	1/10R	BL	MDF tie 6b - not term MDF	4/10R
1AL2	BK	LED 01 panel 1	2/01L	WH	50V supply 1	5/01L
2AL2	BL	LED 02 panel 1	2/01R	BL	PP2040 alarm	5/01R
3AL2	BK	LED 03 panel 1	2/02L	WH	50V supply 2	5/02L
4AL2	OR	LED 04 panel 1	2/02R	BL	signal box alarms	5/02R
5AL2	BK	LED 05 panel 1	2/03L	WH	incoming fuse alarm	5/03L
6AL2	GR	LED 06 panel 1	2/03R	BL	incoming fuse alarm	5/03R
AP3	BK	LED 07 panel 1	2/04L	WH	incoming MF	5/04L
AP1	BR	LED 08 panel 1	2/04R	BL	incoming MF	5/04R
XR2	BK	LED 09 panel 1	2/05L			5/05L
RA2	SL	LED 10 panel 1	2/05R			5/05R
1AL22	YL	LED 01 panel 2	2/06L			5/06L
2AL22	BL	LED 02 panel 2	2/06R			5/06R
3AL22	YL	LED 03 panel 2	2/07L			5/07L
4AL22	OR	LED 04 panel 2	2/07R			5/07R
5AL22	YL	LED 05 panel 2	2/08L			5/08L
6AL22	GR	LED 06 panel 2	2/08R			5/08R
AP23	YL	LED 07 panel 2	2/09L			5/09L
AP21	BR	LED 08 panel 2	2/09R			5/09R
XR22	YL	LED 09 panel 2	2/10L			5/10L
RA22	SL	LED 10 panel 2	2/10R			5/10R
1AL3	VI	LOOP 1 IN	3/01L			
2AL3	BL	LOOP 2 IN	3/01R			
3AL3	VI	LOOP 3 IN	3/02L			
4AL3	OR	LOOP 4 IN	3/02R			
5AL3	VI	LOOP 5 IN	3/03L			
6AL3	GR	LOOP 6 IN	3/03R			
AX6	VI	LOOP 0 IN	3/04L			
	BR	spare	3/04R			
	VI	spare	3/05L			
	SL	spare	3/05R			
R1	GR	LOOP 1 OUT	3/06L			
R2	GR	LOOP 2 OUT	3/06R			
R3	GR	LOOP 3 OUT	3/07L			
R4	GR	LOOP 4 OUT	3/07R			
R5	GR	LOOP 5 OUT	3/08L			
R6	GR	LOOP 6 OUT	3/08R			
R7	GR	LOOP 0 OUT	3/09L			
		spare	3/09R			